

PMV PRO Mini
Quick Start Guide

1. Open the Google Play Store or the Apple App Store
2. Search for "Sigma Mini" or "Sigma Metalytics"
3. Find the app with the name Sigma Mini and this logo: 
4. Install the app to device
5. Turn on the Sigma Metalytics PRO Mini
6. On your tablet or phone, go into WiFi settings and connections
7. Look for the WiFi network named "sigma####" (e.g. sigma1000)
 - a. #### is the serial number on the back of your Sigma Metalytics PRO Mini
8. Connect to the sigma#### network
 - a. The password for the network is the same as the network name
E.g. Network name: sigma1000; Network password: sigma1000
9. Once connected, open the Sigma Mini app
10. The initial screen that opens is used to calibrate your device to accurate measure dimensions
11. Place the supplied calibration coin, found underneath the Sigma Metalytics PRO Mini, in the box on the screen
12. Adjust the box using the +/- buttons until the box perimeter is just touching the outer edge of the calibration coin
13. Press the Save button
14. Now your device is ready for use with the PMV PRO Mini